


SERVICE MANUAL

©2001-4/B51-5726-00 (Z/K)1828

FRONT, CENTER, REAR SPEAKER***Refer to parts list****DISASSEMBLY FOR REPAIR****How to remove the speaker unit**

1. Remove 6 screws from rear side.
2. Remove screws fixing the speaker unit.

SPECIFICATIONS

	Front speaker	Center speaker	Rear speaker
System	1 way (Magnetically shielded)	1 way (Magnetically shielded)	1 way
Enclosure	Bass-Reflex	Bass-Reflex	Bass-Reflex
Loudspeaker	100 mm(4") Cone type (Full Range type)	100mm(4") Cone type (Full Range type)	100 mm(4") Cone typ (Full Range type)
Nominal Impedance	8 Ω	8 Ω	8 Ω
Peak Input Power	-	100W	100 W
Maximum Input Power	100 W(*)	60W	60W
Sensitivity	83 dB / W at 1 m(*)	83 dB / W at 1 m	83 dB / W at 1 m
Frequency Response	100 Hz~20,000 Hz(*)	100 Hz~20,000 Hz	100 Hz~20,000 Hz
Dimensions	Width	128 mm(5-1/16")	128 mm(5-1/16")
	Height	198 mm(7-13/16")	198 mm(7-13/16")
	Depth	126 mm(4-15/16")	126 mm(4-15/16")
Net Weight	1.0 kg	1.0 kg	0.8 kg

* Achieved when both the front speaker and subwoofer SW-05HT driven.


Note:

KENWOOD follows a policy of continuous advancements in development. For this reason specifications may be changed without notice.

KS-205HT/205HT-S

DIVIDING NETWORK UNIT/PARTS LIST

DIVIDING NETWORK UNIT



PARTS LIST

* New Parts

Parts without **Parts No.** are not supplied.

Les articles non mentionnés dans le **Parts No.** ne sont pas fournis.

Teile ohne **Parts No.** werden nicht geliefert.

Ref. No.	Address	New Parts	Parts No.	Description	Destination	Remarks
KS-205HT/205HT-S						
-		*	B46-0310-03	WARRANTY CARD (KS-205HT/-S)	E K P	
-			B46-0328-03	WARRANTY CARD (KS-205HT)		
-			B46-0347-03	WARRANTY CARD (KS-205HT)		
-			B61-1103-00	INSTRUCTION MANUAL		
-			E30-5480-08	SPEAKER CORD (RED/BLACK)		
-			E30-5481-08	SPEAKER CORD (BLUE/BLACK)		
-			E30-5482-08	SPEAKER CORD (GREEN/BLACK)		
-			E30-5483-08	SPEAKER CORD (GLAY/BLACK)		
-			E30-5484-08	SPEAKER CORD (ORANGE/BLACK)		
-		*	H10-8239-08	POLYSTYRENE FOAMED FIXTURE	K P E	
-		*	H10-8240-08	POLYSTYRENE FOAMED FIXTURE		
-		*	H51-1679-08	ITEM CARTON CASE (KS-205HT)		
-		*	H51-1680-08	ITEM CARTON CASE (KS-205HT)		
-		*	H51-1701-08	ITEM CARTON CASE (KS-205HT-S)		
FRONT SPEAKER						
-		*	A21-3444-08	DRESSING PANEL ASSY (KS-205HT)		
-		*	A21-3445-08	DRESSING PANEL ASSY (KS-205HT-S)		
-			E21-0911-08	PUSH TERMINAL (R)		
-			E21-0912-08	PUSH TERMINAL (L)		
SP1		*	T07-0506-05	FULL-RANGE		
CENTER SPEAKER						
-		*	A21-3444-08	DRESSING PANEL ASSY (KS-205HT)		
-		*	A21-3445-08	DRESSING PANEL ASSY (KS-205HT-S)		
-			E21-0913-08	PUSH TERMINAL		
SP2		*	T07-0507-05	FULL-RANGE		
REAR SPEAKER						
-		*	A21-3444-08	DRESSING PANEL ASSY (KS-205HT)		
-		*	A21-3445-08	DRESSING PANEL ASSY (KS-205HT-S)		
-			E21-0914-08	PUSH TERMINAL (R)		
-			E21-0915-08	PUSH TERMINAL (L)		
SP3		*	T07-0508-05	FULL-RANGE		

L: Scandinavia

K: USA

P: Canada

R: Mexico

C: China

I: Malaysia

Y: PX(For East Hawaii)

T: England

E: Europe

G: Germany

V: China(Shanghai)

Y: AAFES(Europe)

X: Australia

Q: Russia

H: Korea

M: Other Areas

△ indicates safety critical components.